

The Guide of flashing this beta BIOS

on X99 Platform

Step1. If there are two pcs R9 295 VGA cards or other PCI/PCI-E cards on your system, please remove these add-on cards and only install one pcs R9 295 VGA card to your system.

Before updating this beta BIOS, please make sure only one VGA card is installed on your system.

Step 2. Please boot up system with 1 pcs VGA card and enter into BIOS setup.

Step 3. Please press “F9” to load BIOS default settings and then enter “F10” to save the settings and exit.

Step 4. After loading default settings under BIOS, please enter into BIOS setup and then use ASRock Instant Flash to update this beta BIOS.

Step 5. When flashing the BIOS successfully, please install all add-on cards to your system and then check if your system is working well.

If any questions, please feel free to contact ASRock TSD by the following link and we'll assist you shortly.

Technical Contact Link: <http://event.asrock.com/tsd.asp>